

亚洲安防科技股份有限公司

ASIA SECURITY TECHNOLOGY LIMITED

6-17, Overseas People Venture Park, No.108, JiangBin Road East, Economic & Technological Development Zone, Fuzhou 350015, China Tel: (86-591) 2229 0811(10lines) Fax: (86-591) 8354 3611 Web: www.asst.hk www.chuango.com

Operation manual for wireless shutter door sensor (MC-55)

Recoding: Press the recoding button of the alarm control panel, part the magnet away the steel reed pipe, you will hear one dee sound from the panel it means the recoding is successful.

Installation place: on shutter door of shop or garage.

Installation: fix the steel reed pipe on the ground, put the transmitter on the near wall, and then place the magnet on the bottom edge of the shutter door, which should be rightly upper the steel reed pipe. When the gap from the magnet to the steel reed pipe is more than 5cm, the transmitter will send alarm signal to the control panel.

